


## RT-2400/5100/5100S Accessories Guidelines



- ① Floor Mount
- ② Wall Mount
- ③ 2\*110mm Series/Parallel Cable Between Batteries
- ④ 1\*280mm Communication Cable Between Batteries
- ⑤ 2\*1500mm Power Cable Between Battery and Inverter
- ⑥ 1\*1500mm Communication Cable Between Battery and Inverter
- ⑦ 1\*350mm Ground Wire Between Batteries